

<b>DTC</b>	<b>C1257/57</b>	<b>IG Power Source</b>
------------	-----------------	------------------------

**DESCRIPTION**

The motor relay (semiconductor relay) is built into the hydraulic brake booster and drives the pump motor based on a signal from the skid control ECU.

DTC No.	DTC Detecting Condition	Trouble Areas
C1257/57	Open in pump motor input circuit	Hydraulic brake booster pump motor circuit

<b>1</b>	<b>CHECK HYDRAULIC BRAKE BOOSTER PUMP MOTOR OPERATION</b>
----------	---

- (a) Turn the ignition switch to OFF.
- (b) Disconnect the actuator connector (S1).
- (c) Depress the brake pedal more than 20 times.
- (d) Check the hydraulic brake booster pump motor operation.

**OK:**

**Hydraulic brake booster pump operates.**

<b>NG</b>	<b>REPLACE MASTER CYLINDER SOLENOID</b>
-----------	---

OK

<b>2</b>	<b>RECONFIRM DTC</b>
----------	----------------------

- (a) Turn the ignition switch to OFF.
- (b) Reconnect the actuator connector (S1).
- (c) Turn the ignition switch to the ON position.
- (d) Clear the DTCs (See page [BC-118](#)).
- (e) Check if the same DTCs are recorded.

BC

Result	Proceed to
DTC output	A
DTC not output	B

<b>B</b>	<b>END</b>
----------	------------

A

<b>REPLACE MASTER CYLINDER SOLENOID</b>
---


**DTC****C1258/58****Transfer 4WD Position Switch Circuit****DESCRIPTION**

This circuit monitors whether the transfer is in 2WD or 4WD mode and inputs the signal to the skid control ECU. In 2WD mode, TRAC is activated.

In 4WD mode, A-TRAC is activated.

DTC No.	DTC Detecting Conditions	Trouble Areas
C1258/58	<ul style="list-style-type: none"> <li>• 4WD: Open in 4WD detecting circuit</li> <li>• 2WD: Terminal NEO ground short, or abnormal signals transmitted to terminal EXI</li> </ul>	<ul style="list-style-type: none"> <li>• Transfer indicator switch (4WD position)</li> <li>• Transfer indicator switch (4WD position) circuit</li> <li>• Master cylinder solenoid (skid control ECU)</li> </ul>

WIRING DIAGRAM



BC

C12477E01

NOTICE:

When replacing the master cylinder solenoid, perform zero point calibration (See page BC-99).

**1 CONFIRM VEHICLE TYPE**

(a) Confirm the vehicle drive train.


Drive Train	Proceed to
4WD	A
2WD, Pre-Runner	B

**A**

**B** **Go to step 7**

**2 INSPECT SKID CONTROL ECU (EXI TERMINAL VOLTAGE)**

Skid Control ECU  
(harness side connector):



C121700E16

- (a) Disconnect the skid control ECU connector.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage.

**Standard**

Tester Connection	Transfer Condition	Specified Condition
S1-27 (EXI) - Body ground	2WD	8 to 16 V
S1-27 (EXI) - Body ground	4WD	Below 1.5 V

- (d) Turn the ignition switch to OFF.
- (e) Reconnect the skid control ECU connector.

**OK**

**NG** **Go to step 4**

**BC**

**3 RECONFIRM DTC**

- (a) Clear the DTCs (See page [BC-118](#)).
- (b) Check if the same DTCs are recorded.


Result	Proceed to
DTC output	A
DTC not output	B

**A**

**NG** **END**

**REPLACE MASTER CYLINDER SOLENOID**

**4 INSPECT TRANSFER INDICATOR SWITCH (4WD POSITION)**



- (a) Disconnect the transfer indicator switch (4WD position) connector.
- (b) Remove the transfer indicator switch (4WD position).
- (c) Measure the voltage.

**Standard**

Tester Connection	Switch Position	Specified Condition
1 - 2	Pushed	Below 1 Ω
1 - 2	Free	10 kΩ or higher

- (d) Reinstall the transfer indicator switch (4WD position).
- (e) Reconnect the transfer indicator switch (4WD position) connector.


**NG** **REPLACE TRANSFER INDICATOR SWITCH (4WD POSITION)**

**OK**

**5 CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - ECM)**


Skid Control ECU  
(harness side connector)

(S1)




1GR-FE:

ECM



2TR-FE:

ECM



- (a) Disconnect the skid control ECU connector.
- (b) Disconnect the ECM connector.
- (c) Measure the resistance.

**Standard (1GR-FE)**

Tester Connection	Specified Condition
S1-27 (EXI) - B6-8 (4WD)	Below 1 Ω

**Standard (2TR-FE)**

Tester Connection	Specified Condition
S1-27 (EXI) - B5-21 (4WD)	Below 1 Ω

- (d) Reconnect the ECM connector.
- (e) Reconnect the skid control ECU connector.

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR


BC

F052062E01


**OK**

**6 CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - 4WD CONTROL ECU)**

**Skid Control ECU  
(harness side connector)**



**4WD Control ECU  
(harness side connector)**



F052382E01

- (a) Disconnect the skid control ECU connector.
- (b) Disconnect the 4WD control ECU connector.
- (c) Measure the resistance.

**Standard**

Tester Connection	Specified Condition
S1-27 (EXI) - F13-26 (ADD)	Below 1 Ω

- (d) Reconnect the 4WD control ECU connector.
- (e) Reconnect the skid control ECU connector.

**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**


**OK**

**END**

**BC**

**7 CHECK HARNESS AND CONNECTOR (NEO TERMINAL - BODY GROUND)**

**Skid Control ECU  
(harness side connector):**



C121700E17

- (a) Disconnect the skid control ECU connector.
- (b) Measure the resistance.

**Standard**

Tester Connection	Vehicle Drive Train	Specified Condition
S1-10 (NEO) - Body ground	2WD, Pre-runner	10 kΩ or higher
S1-10 (NEO) - Body ground	4WD	Below 1 Ω

- (c) Reconnect the skid control ECU connector.


**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**8 RECONFIRM DTC**

- (a) Clear the DTCs (See page [BC-118](#)).
- (b) Check if the same DTCs are recorded.

Result	Proceed to
DTC output	A
DTC not output	B



**REPLACE MASTER CYLINDER SOLENOID**